

PRODUCT DATA



EPOXY CHOCK High Performance Epoxy Chock

PRODUCT DESCRIPTION

Five Star® Epoxy Chock is an epoxy chock system specifically engineered for use under integral gas compressors, skid mounted equipment, turbines, generators, and other critically aligned machinery. Five Star Epoxy Chock is a two component, 100% solids, solvent free material providing excellent flowability and high compressive strength at elevated temperatures and loading conditions. Five Star Epoxy Chock is an economical replacement for steel chocks because it eliminates costly machining and provides virtually 100% contact to machinery base plates.

ADVANTAGES

- Permanent support for machinery requiring precision alignment
- Chemically resistant
- Pourable two component system
- Eliminates costly machining

USES

- Compressors
- Hot-running machinery
- Turbines and generators
- Replacement for steel chocks
- Motors and pumps

PACKAGING AND YIELD

Five Star Epoxy Chock is a two component chocking system consisting of partially filled containers of resin and hardener and is available in a unit yielding approximately 0.15 cubic feet (4.3 liters).

SHELF LIFE

Two years in original unopened packaging when stored in dry conditions; high relative humidity will reduce shelf life.

TYPICAL PROPERTIES AT 70°F (21°C)		
	NEAT	30% SAND EXTENSION
Compressive Strength, ASTM C 579 B Post Cure @ 140°F (60°C)	19,500 psi (134 MPa)	19,000 psi (131 MPa)
Compressive Secant Modulus	9.0 x 10 ⁵ psi (0.62 x 10 ⁴ MPa)	9.0 x 10 ⁵ psi (0.62 x 10 ⁴ MPa)
Coefficient of Linear Thermal Expansion, ASTM C 531, 32°F to 140°F (0°C to 60°C)	16.7 x 10 ⁻⁶ in/in/°F (29.5 x 10 ⁻⁶ mm/mm/°C)	16.0 x 10 ⁻⁶ in/in/°F (28.3 x 10 ⁻⁶ mm/mm/°C)
Linear Shrinkage, ASTM C 580	0.0002 in/in	0.0002 in/in
Flexural Strength, ASTM C 580	6500 psi (45 MPa)	6200 psi (43 MPa)
Tensile Strength, ASTM C 307	3000 psi (21 MPa)	2800 psi (19 MPa)
Pot Life 70°F (21°C)	30 Minutes	45 Minutes
Fire Resistance, ASTM D 635	Self Extinguishing	Self Extinguishing
Colour	Blue	Blue

The data shown above reflects typical results based on laboratory testing under controlled conditions. Reasonable variations from the data shown may result. Test methods are modified where applicable.

PLACEMENT GUIDELINES

- 1. SURFACE PREPARATION:** All surfaces to be in contact with Five Star® Epoxy Chock shall be free of oil, grease, and other contaminants. Steel surfaces with sharp edges or frets should be smoothed prior to pouring in order to prevent possible cracks in the epoxy chock.
- 2. FORMWORK:** Open celled foam or similar material should be installed on three sides of the chock area. The foam dam must fit firmly between the machinery bedplate and the foundation to provide a liquid-tight seal. Anchor bolts must be sprayed with a suitable release agent. Any jacking bolts that are located inside the chock area must also be treated with a suitable release agent. The entire chock area must be sprayed with release agent prior to installing the front dam. Check the chock area for any possible locations that could cause a leak and seal accordingly. Install a front dam made of steel angle iron or flat bar approximately 3/4 inch (18 mm) to 1 inch (25 mm) away from the machinery bedplate and high enough to allow the chocking material to be poured 1/2 inch (12 mm) above the bottom of the bedplate. Spray the inside of the front dam with release agent. Machinery must be in final alignment position prior to pouring Five Star Epoxy Chock.
- 3. MIXING:** For optimum performance, resin and hardener should be conditioned to between 21°C (70°F) and 27°C (80°F) for at least 12 hours before use. Premix Component A (resin) for approximately one minute. Pour Component B (hardener) into the Component A (resin) container and mix thoroughly for three to four minutes with a slow speed drill and paddle mixer at 200 rpm. Always keep the mixing blade completely submerged in the chocking material to minimize air entrapment. Be certain the mixing blade removes material completely around the sides and bottom of the resin can. This will ensure a uniform mix of the resin and hardener. Use oven-dried sand when extending Five Star Epoxy Chock.
- 4. POURING:** Always pour Five Star Epoxy Chock from the lowest side of the chock area which will force air to escape through the open celled foam at the opposite corner. Continue to pour slowly until the entire chock area is filled and the chock overpour area is filled to a level approximately 1/2 inch (12 mm) above the bottom of the bedplate.
NOTE: Do not scrape material from the sides of the container, use only material that flows freely from container. Be sure that all the chocks have hardened before leaving the area of the pour. For pour placements less than 1/2 inch (12 mm) or greater than 2 1/2 inches (63 mm) or 0.15 cubic feet (4.3 liters), contact StonCor at (800) 263.3112.
- 5. POST-PLACEMENT PROCEDURES:** Make sure the chocks have cured properly based on the following steel temperatures and curing times, then remove the front dam, release jacking bolts, tighten anchor bolts to recommended torque or tension.
- 6. CLEAN UP:** All tools and equipment may be cleaned with a solvent before material hardens. Sand may be used as an abrasive.
NOTE: NOTE: PRIOR TO APPLICATION, READ ALL PRODUCT PACKAGING THOROUGHLY. For more detailed placement procedures, refer to Design-A-Spec™ installation guidelines or call StonCor at (800) 263.3112.

CONSIDERATIONS

- For pour placements less than 1/2 inch (12 mm) or greater than 2 1/2 inches (63 mm) or exceeding 0.15 cubic feet (4.3 liters), contact StonCor at (800) 263.3112.
- Flowability and cure times gain are adversely affected by lower temperatures.

CAUTION

Irritant, toxic, strong sensitizer. Contains epoxy resin and amine. This product may cause skin irritation. Do not inhale vapours. Provide adequate ventilation. Protect against contact with skin and eyes. Wear rubber gloves, long sleeve shirt, goggles with side shields. In case of contact with eyes, flush repeatedly with water and contact a physician.

For worldwide availability, additional product information and technical support, contact your local sales representative, or call StonCor at (800) 263.3112.

Steel Temperature	Cure Time
13°C to 15°C (55°F to 60°F)	48 hours
16°C to 18°C (61°F to 65°F)	36 hours
19°C to 21°C (66°F to 70°F)	24 hours
Above 23°C (Above 75°F)	18 hours

WARRANTY: "FIVE STAR PRODUCTS INC. (FSP) PRODUCTS ARE MANUFACTURED TO BE FREE OF MANUFACTURING DEFECTS AND TO MEET FSP'S CURRENT PUBLISHED PHYSICAL PROPERTIES WHEN APPLIED IN ACCORDANCE WITH FSP'S DIRECTIONS AND TESTED IN ACCORDANCE WITH ASTM AND FSP STANDARDS. HOWEVER, SHOULD THERE BE DEFECTS OF MANUFACTURING OF ANY KIND, THE SOLE RIGHT OF THE USER WILL BE TO RETURN ALL MATERIALS ALLEGED TO BE DEFECTIVE, FREIGHT PREPAID TO FSP, FOR REPLACEMENT. THERE ARE NO OTHER WARRANTIES BY FSP OF ANY NATURE WHATSOEVER, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IN CONNECTION WITH THIS PRODUCT. FSP SHALL NOT BE LIABLE FOR DAMAGES OF ANY SORT, INCLUDING PUNITIVE, ACTUAL, REMOTE, OR CONSEQUENTIAL DAMAGES, RESULTING FROM ANY CLAIMS OF BREACH OF CONTRACT, BREACH OF ANY WARRANTY, WHETHER EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR FROM ANY OTHER CAUSE WHATSOEVER. FSP SHALL ALSO NOT BE RESPONSIBLE FOR USE OF THIS PRODUCT IN A MANNER TO INFRINGE ON ANY PATENT HELD BY OTHERS."

Important:

StonCor believes the information contained here to be true and accurate as of the date of publication. StonCor makes no warranty, expressed or implied, based on this literature and assumes no responsibility for consequential or incidental damages in the use of the systems described, including any warranty of merchantability or fitness. Information contained here is for evaluation only. We further reserve the right to modify and change products or literature at any time and without prior notice.

11/09

STONCOR Group
An RPM Company 95 Sunray Street • Whitby, Ontario • L1N 9C9 • Tel: 800.263.3112 • Fax: 800.786.6329

Vancouver • Calgary • Edmonton • Regina • Saskatoon • Winnipeg • Toronto • Ottawa • Halifax
Saint John • St. John's • Montreal • Gatineau • Québec • Sherbrooke • Trois-Rivières • Chicoutimi

www.stoncorcpg.ca